



QUICK START
GUIDE

ROVINS

GYRO TO INS

Objective

This guide describes how to install the ROVINS, and the basic configurations required before beginning the positioning

Contents

OBJECTIVE.....	01
CONTENTS.....	01
CONVENTIONS.....	02
ROVINS SYSTEM OVERVIEW.....	03
VERIFICATION OF PACK CONTENTS.....	03
BASIC INSTALLATION.....	03
STEP 1 - INSTALLING ROVINS.....	05
STEP 2 - ACTIVATING THE PRODUCT LICENSE.....	10
STEP 3 - CONFIGURING ROVINS.....	19
STEP 4. NAVIGATING WITH ROVINS.....	24
MORE.....	25
CUSTOMER SUPPORT.....	29
IXSEA CONTACT.....	30

CONVENTIONS

The following conventions are used in this guide

► The ► symbol leads you through nested menu items and/or dialog box options to a final action.
Example:
Logging ► Configure Logging Parameters means “Select **Configure Logging Parameters** option from the **Logging** pull down menu”.

bold Bold text is used for items you must select or click in the software.
It is also used for the field names used into the dialog box.

Courier Text in this font denotes text or characters that you should enter from the keyboard, the proper names of disk Drives, paths, directories, programs, functions, filenames and extensions.

italic Italic text is the result of an action in the procedures.

ROVINS SYSTEM OVERVIEW

The ROVINS system is an Inertial Navigation System (INS). It delivers heading and attitude information as well as position and speed, to other systems or to display. It can receive data from other sensors to improve its accuracy. The ROVINS system can also be used as a gyrocompass. The core of ROVINS is an inertial measurement unit (IMU). The IMU is the assembly of three fiber optic gyroscopes (FOG) manufactured by IXSEA and three high precision pendulum-type accelerometers.

Apart from its IMU, ROVINS contains a self-consistent navigation algorithm based on Kalman Filtering. This structure enables ROVINS to work either as a black box or to be connected to external sensor systems (GPS, Doppler Velocity Log, Depth sensor, acoustic positioning systems ...). In conjunction with external sensors, ROVINS Kalman filter exceeds by several orders of magnitude the performances obtained with traditional navigation approaches

ROVINS is delivered with a powerful and easy-to-use WEB-Based User Interface, which allows a complete configuration.

VERIFICATION OF PACK CONTENTS

You will find in the shipping case a Packing List detailing all the items delivered. This packing has been completed and checked by IXSEA shortly before shipment, and should match the contents of the pack you have received.

However, we recommend that you check the contents of the pack and the equipment immediately on receipt of your ROVINS unit. Specifically, you should check that all the items referred to above are present on delivery and that none has sustained damage.

If you observe any non-conformity or damage, please inform the carrier and IXSEA without delay by certified mail, describing in detail the problem encountered.

BASIC INSTALLATION


This guide describes how to install ROVINS with a GPS, and the basic configurations required before beginning the positioning. This is the basic installation. If you need to install additional external sensors, to define lever arms and/or to enter installation biases, please refer to ROVINS User Guide. ROVINS being versatile, you have to define its configuration to insure optimal operation.

In this installation, we assume that ROVINS is aligned with respect to the vessel reference frame.

This configuration includes:

- Defining how ROVINS is installed on board (ROVINS orientation with respect to the vessel reference frame, ROVINS and GPS lever arms)
- The cable connections to other equipment (connection to the workstation, connection to the GPS)
- The activation of the product license
- The communication link, the serial or Ethernet link, the activation of the GPS , the pulse input for Time synchronization System i.e., all settings to enter into ROVINS using the WEB-based User Interface
- Navigation

Step 1: Installing ROVINS + GPS



Step 2: Activating the product license

LICENSE ACTIVATION

Send your license ID below to support. You will receive an activation code by mail to start using the system

License state: **Not yet activated**

License ID: **A3D6F534127DDFE4**

Activation code:

Activate license

Step 3: Configuring

To define the ROVINS orientation, lever arms, and the PC-ROVINS communication parameters
 To configure the GPS: serial or Ethernet input parameters, lever arm

To define the Time Synchronisation system

To define the initial position

To activate the license code

IXSEA ROVINS

navigation data | maintenance | options

CONTROL | **INSTALLATION** | SETUP | DATA LOGGING

Heading 45.253° Roll 1.187° Pitch -0.874° Heave 0.78 m Speed 2.35 kt

Latitude 43.18221° Longitude 5.63354° Depth 25.3 m STATUS System ready

DETAILED STATUS

- Input
- Output
- System: Navigation mode, Alignment, Fine alignment
- Ext. Sensors: Stabilization, GPS valid, USBL valid, Depth valid, LBL valid, GPS reception, USBL reception, LBL reception, Depth reception, UTC synchro, Sound velocity reception


EXTERNAL SENSORS

GPS ON LBL ON DVL BT OFF DVL WT OFF

USBL ON Depth ON ZUPT OFF

To activate the GPS (i.e., to take the GPS data into account by the Kalman filter)

Step 4: Navigating with ROVINS



STEP 1- INSTALLING ROVINS

ROVINS is fixed onboard using six CHC M6 screws. It can be installed with any orientation with respect to the vessel (see the definition of the vessel reference frame hereafter). The alignment of the unit is performed by means of the two centering pins located on the bottom plate of the ROVINS. You will find on Figure 1 all the mechanical information necessary to fix ROVINS. All inertial measurements are default performed with respect to ROVINS reference frame (X1, X2, X3). This reference frame is defined in Figure 1. Motion sensing measurements are default measured at ROVINS Center of Measurement P (see Figure 1).





Figure 1 – Definition of ROVINS Reference Frame (X1,X2, X3) and P center of measurements

Recommendations and Note

- Temperature in operation must be in the range -20 °C to 55 °C
- The dimensions of the ROVINS housing are (l x Ø) in mm): 374 x 213. There must be enough place for the wire way on the connector side of ROVINS
- The weight of ROVINS is 14.6 in air and 4.65 in sea water

TRUE HEADING, ROLL AND PITCH DEFINITIONS




The roll is defined as the angle of rotation performed around the vessel $XV1$ so that the vessel axis $XV2$ lies in the local horizontal plane. This angle is default defined positive in the direction of axis $XV1$, i.e., when the boat port side is up. It varies between -180 and $+180^\circ$. The figure above is an illustration of the roll angle with null pitch.

Once the axis $XV2$ lies in the local horizontal plane, the pitch is the angle between the axis $XV1$ of the vessel and its projection in the local plane. This angle is default defined positive in the direction of the axis $XV2$, i.e., when the boat bow is down. It varies from -90 to $+90^\circ$. The figure above is an illustration of the pitch angle in case of null roll.


Once the axes $XV2$ and $XV1$ lie in the local horizontal plane, the true heading is the angle between the vertical plane oriented in the North direction and the vertical plane passing through the vessel. Heading is counted positive from North, varying from 0 to 360° . The orientation of this angle is given above in case of null pitch and roll.

Electrical Connections: GPS + PPS (optional for Time synchronization) Standard Ethernet Link Case

Standard case defined as follows:
 External sensor connected to the ethernet stream A of ROVINS:
 GPS Output protocol on stream A: GPS like
 PPS time synchronization pulse from the GPS cabled on the Pulse input B of ROVINS




GPS Antenna, Power supply, workstation connected to the Ethernet connector




PIN	Signal	PIN	Signal
1	Ext sensor 1 In (+V1)	11	Pulse B: OUT TTL
2	Ext sensor 1 In GND (0/+V1 V)	12	Ext Pulse IN -
3	Ext sensor 2 In (+V2)	13	GND_B
4	Ext sensor 2 In GND (0/+V2 V)	14	Shield Ethernet
5	Repeater: RS232 TX(+)	15	Ethernet TX(+)
6	Repeater RS232 RX(+)	16	Ethernet TX(-)
7	Ext Pulse IN +	17	Pulse B: IN TTL
8	ROVINS Power In (+24 V)	18	Ethernet RX(+)
9	ROVINS Power In GND (0/24 V)	19	Ethernet RX(-)
10	Repeater: GND_R		

ELECTRICAL CONNECTIONS: GPS + PPS (OPTIONAL FOR TIME SYNCHRONIZATION) SERIAL LINK CASE (WHEN ETHERNET CONNECTION IS NOT POSSIBLE)

Case when Ethernet connection is not possible:
 External sensor connected to the serial link A of ROVINS: GPS
 Output protocol on serial link A: GPS like
 PPS time synchronization pulse from the GPS cabled on the Pulse input A of ROVINS In this case the workstation establishes a PPP connection with ROVINS
 Refer to the ROVINS User Manual to know how to configure this PPP connection



GPS Antenna, Power supply, workstation connected to the Central connector



STEP 2. ACTIVATING THE PRODUCT LICENSE (ONLY FOR UPGRADE CASE)

As soon as ROVINS is powered up it starts its alignment phase starting with the manually input position stored into ROVINS PROM. It is required that a valid initial position is input manually (see Step 3) or is given by the GPS. The alignment sequence is detailed in Step 4.

Launching the WEB-based User Interface


Required environment :

- The workstation must be equipped with one of the following Web browser:
 - Mozilla Firefox version 3.5 and higher
 - Chrome version 4 and higher
 - Safari version 4 and higher
 - Opera version 10 and higher
 - Internet Explorer version 7 and higher
- Flash Player version 10 (and higher) must be installed on the workstation to visualize the compass
- For the data logging: Java Runtime Environment 1.6 (and higher)

They can be installed on your workstation from the provided IXSEA CD-ROM.

The communication with the workstation is performed directly through the Ethernet link.

ROVINS *Web-based User Interface* is then launched from the WEB browser hosted on the workstation. Its URL address is 192.168.36.1xx, xx being the two last numbers of the ROVINS serial number:



The Control Pages opens:

During the first seconds the IXSEA logo is flashing gray/blue indicating that the *Web-based User Interface* is loading the internal configuration of ROVINS. Then the logo turns blue, the alignment sequence of ROVINS begins.

RS232	Central connector
Function	Link A
Tx	Pin 11
Rx	Pin 13
Tx Rx GND_A	Pin 8

Power	Central connector
Function	
In	Pin 1
In GND	Pin 2

Repeater/com with workstation RS232	Central connector
Function	Repeater
Tx	Pin 9
Rx	Pin 15
Tx Rx GND_R	Pin 5

RS422	Central connector
Function	Link A
Tx +	Pin 11
Tx -	Pin 12
Rx +	Pin 14
Rx -	Pin 13
Tx Rx GND_A	Pin 8

Repeater/com with workstation RS422	Central connector
Function	Repeater
Tx +	Pin 9
Tx -	Pin 10
Rx +	Pin 16
Rx -	Pin 15
Tx Rx GND_R	Pin 5

Pulse In	Central connector
Function	Pulse A
IN TTL	Pin 20
GND_A	Pin 21

WEB-BASED USER INTERFACE - GENERAL RULES, COMMANDS AND NAVIGATION

IXSEA logo handling

A click on the IXSEA logo opens the detailed status/activation pop-up window and the compass disappears.

- This window:
 - Sums-up the status of
 - The input ports
 - The output ports
 - The system
 - The external sensors
 - Enables the external sensors activation

The screenshot shows the IXSEA web interface with a detailed status pop-up window. The main interface displays navigation data, system status, and a compass. The pop-up window provides a detailed overview of the system's status and external sensor activation options.

IXSEA navigation data | maintenance | options

CONTROL | INSTALLATION | SETUP | DATA LOGGING

Heading 45.253°
 Roll 1.187°
 Pitch -0.874°
 Heave 0.78 m
 Speed 2.35 kt

Latitude 43.18221°
 Longitude 5.63354°
 Depth 25.3 m

STATUS
 System ready

DETAILED STATUS

- Input**
- Output**
- System**
 Navigation mode
 Alignment
 Fine alignment
- Ext. Sensors**
 Stabilization
 GPS valid
 USBL valid
 Depth valid
 LBL valid
 GPS reception
 USBL reception
 LBL reception
 Depth reception
 UTC synchro
 Sound velocity reception

EXTERNAL SENSORS

GPS ON OFF LBL ON OFF DVL BT ON OFF DVL WT ON OFF
 USBL ON OFF Depth ON OFF ZUPT ON OFF

You can close the pop-up by clicking on the IXSEA logo.

The screenshot shows the IXSEA web interface with several callouts explaining UI elements:

- Menu Bar:** The menu is blue when selected.
- Maintenance page:** Firmware upgrades, system restarting, factory settings reset, support contact.
- options page:** position selection, language selection, day/night mode selection.
- Navigation data window:** It displays all data either computer by ROVINS or coming from external sensors.
- Heading, Roll, Pitch, Heave and Speed data:** Heading 45.253°, Roll 1.187°, Pitch -0.874°, Heave 0.78 m, Speed 2.35 kt.
- System Status: color and verbose display:** STATUS System ready.
- Latitude, Longitude and Depth or UTM positions and Depth data:** Latitude 43.18221°, Longitude 5.63354°, Depth 25.3 m.
- UTM northing, UTM easting, and Depth:** UTM northing 4784416.50 m, UTM easting 714025.03 m, Depth 25.30 m.
- Compass area:** A compass display showing heading and orientation.

Color Code

The color code applies for the indicators and text labels displayed in this pop-up window. When a problem occurs, the color of the IXSEA logo changes and the detailed status pop-up automatically appears showing immediately which equipment has raised the problem.

Table 1 – Color code definition


Color	Definition
Grey	inactivity
Flashing Grey/Blue	System Configuration (during initialization for example)
Blue	Activity, nominal operation
Orange	Activity, warning
Red	Activity, alarm

General Rules for Using Command Windows

The command windows allow you to display or modify ROVINS configuration parameters. At first delivery, these parameters are set to default values. You have to modify them to fit your needs:

Scrolling list selection

- By selecting it directly in the scrolling list:



Note

you can also use the up arrow ([↑]) and down arrow ([↓]) keys to scroll in the list.

Tick box

- By selecting it by clicking in the dedicated box:




Text box

- By typing it in the dedicated area:



Note

You can also use the up arrow ([↑]) and down arrow ([↓]) keys to increase or decrease the numerical values. Incorrect value are immediately indicated by red color:



Expanding hidden area

In order to keep each web-based page as small as possible, only the main parameters are default visible. You can expand the hidden area by clicking on its text label title:

OK/Cancel buttons

Each command page contains the same buttons, they appear as soon as a modification or a selection has been made in the command page:



To validate the new configuration and store it in the ROVINS PROM.



To return to the previous entered values.

Other Button




On "mouse over" action, orange color may surround a button to indicate that the action performed by clicking on the button has consequences.

Examples of such action:

- ROVINS restart (the alignment process is repeated)
- Reset to factory settings (the customized configuration is lost)


PRODUCT LICENSE ACTIVATION (ONLY IN CASE OF UPGRADE)




Step 1: Ask for the activation code: click on maintenance menu on the ROVINS Web-based User Interface.



Step 2: To recover the activation code, using the «Contact Support» button, send a message to IXSEA support giving your ROVINS license ID.



Step 3: Enter the recovered activation code in the dedicated text box and click «Activate License» button.



WEB-BASED USER INTERFACE - MENUS AND OPTIONS OVERVIEW









Find hereafter all the menus and options of the WEB-based User Interface and their uses

Menu /options	Used to ...
	<p>Define the ROVINS orientation, possible roll, pitch and heading misalignments, primary and secondary lever arms useful to compute the heave and position for the output protocols that provide it</p>
	<p>Define the couple (external sensor or UTC, input link): the protocol used to input the data, the serial (parity, baud rate, standard (RS232 or RS422) and stop bit) or Ethernet (transport layer, IP address, Port number) parameters, and the external sensor parameters (lever arms, misalignments (for the DVL), beacon selection (for the USBL))</p> <p>Define the Time synchronization settings (UTC): pulse input selection for the PPS signal, the protocol to use for the PPS signal</p>

Menu /options	Used to ...
	<p>Define the outputs: the protocol used to output the data, the lever Arm to use, the data rate or the input pulse to use to synchronize the output data, the serial (parity, baud rate, standard (RS232 or RS422) and stop bit) or Ethernet (transport layer, IP address, Port number) parameters, the pulse output to output the envelop, the heave filter to use</p>
	<p>Define the Network parameters for communication through a serial link (PPP option) or through Ethernet one (DHCP client mode activation, ROVINS IP address and Network mask to use)</p>
	<ul style="list-style-type: none"> • Enter the initial position, save it, update it • Choose the Zero Velocity mode
	<ul style="list-style-type: none"> • To be informed in case of warning or error for <ul style="list-style-type: none"> UTC synchronization loss Position sensor loss Speed loss • To generate a warning when the heading and/or the position standard deviation cross a defined threshold

Menu /options

Used to ...

	<p>To launch the DVL calibration</p>
	<p>To save /restore product settings</p>
	<p>Log the data of the repeater output or of any A to E output.</p>
	<ul style="list-style-type: none"> Restart your ROVINS Unit Update the system: firmware, loader, and/or WEBBasedUser Interface versions To activate your license by entering the activation code Get ROVINS serial number and WEB-based User Interface Contact IXSEA Support
	<p>Display all navigation data computed and received by ROVINS</p>
	<p>Choose the position coordinate representation (latitude/longitude or UTM coordinates)</p>
	<p>Choose the display mode (night/day mode)</p>
	<p>Choose the WEB-based language (English or French)</p>

STEP 3. CONFIGURING ROVINS

CONFIGURING THE ROVINS ORIENTATION WITH RESPECT TO THE VEHICLE



As ROVINS can be installed with any orientation with respect to the vehicle, ROVINS axes orientation can be different from vehicle axes orientation, with 90 degrees rotations of any of the ROVINS axis with respect to the vehicle axes.

Step 1: Choose **MECHANICAL PARAMETERS** under **INSTALLATION** Menu

- Step 2:**
- The direction to which the IXSEA logo side is pointing.
→ In the illustration, ROVINS logo side points to the chosen direction.
 - The direction to which the ROVINS connectors side is pointing.
→ In the illustration, ROVINS connectors side points to the chosen direction.


Step 3: Click the **OK** button to validate your choice.

- Step 4:** Click on **Restart** button in the warning window that appears in the upper part of the Mechanical Parameters page.
→ ROVINS restarts, and alignment sequence (see step. 4) is repeated.




CONFIGURING THE GPS INPUT STREAM AND GPS PARAMETERS

Step 1: Choose **INPUTS** under **INSTALLATION** Menu



Step 2: Associate **GPS** to **INPUT A** by clicking in the intersection of the **INPUT A** column and **GPS** row




Step 3: Configure the relevant parameters of the **INPUT A** by choosing them in the various drop-down lists of the Protocol, Physical Link, Serial and/or Ethernet areas.



Step 4: Define the GPS lever arms:

- LV1 is the signed distance from the ROVINS center of measurements to the GPS along axis 1 of the illustration
- LV2 is the signed distance from the ROVINS center of measurements to the GPS along axis 2 of the illustration
- LV3 is the signed distance from the ROVINS center of measurements to the GPS along axis 3 of the illustration



Step 5: Click **OK** to validate and save your choices.




Step 6: Activate the GPS (i.e., take into account the GPS data into the ROVINS Kalman filter): In EXTERNAL SENSORS area (that is the detailed status pop-up in the CONTROL page), set the activation parameter of the GPS to ON position by clicking on OFF button.



CONFIGURING THE PPS FOR USING TIME SYNCHRONIZATION SYSTEM

Step 1: Choose **INPUTS** under **INSTALLATION** Menu



Step 2: Associate **UTC** to **INPUT A** by clicking in the intersection of the **INPUT A** column and **UTC** row



Step 3: • For an Ethernet link, the pulse input will come from pulse input B: choose Ethernet for the Physical Link then select Pulse B for Synchro In and the desired protocol
• For a serial link, the pulse input will come from pulse input A: choose Serial for the Physical Link then select Pulse A for Synchro In and the desired protocol.

Step 4: Click **OK** to validate and save your choices.

CONFIGURING THE OUTPUT STREAM

Step 1: Choose **OUTPUTS** under **INSTALLATION** Menu




Step 2: Click on **Output A**.

Step 3: Choose «GPS like» in the **Protocol** list

Step 4: Select the **Physical Link** and configure its parameters if needed.

Step 5: Click **OK** to validate and save your choices.



ENTERING THE INITIAL POSITION


Entering the initial position is only necessary if no GPS is available upon starting ROVINS. Once saved by clicking on OK button, the entered position is used at next ROVINS start.

Step 1: To define the position :

- Click options menu

In the Coordinate System area :

- Either select Latitude/longitude option
- Or UTM option
- Click **OK** button to validate




Step 2: Choose **INIT&UPDATE** under **SETUP** Menu




Step 3: Enter the initial position:

- Either Latitude (in degrees), Longitude (in degrees) and depth (in meters)



- or the UTM coordinates of this position



Step 4: Click **OK** to validate and save your choices.

STEP 4. NAVIGATING WITH ROVINS

As soon as ROVINS is powered on, it starts its alignment phase with the manually input position stored into ROVINS PROM.

- During the first five minutes after powering-on, ROVINS performs its coarse alignment: ROVINS inertial sensor data (accelerometers and gyrometers) are computed to estimate heading, roll and pitch angles. At sea it is recommended that the system is kept as steady as possible during coarse alignment: oscillations around a mean position are permitted but accelerations should be avoided. Leaving the vessel adrift for 5 minutes would lead to satisfactory conditions for coarse alignment.
- After the first five minutes long coarse alignment phase, ROVINS switches to the “fine alignment” phase to improve the accuracy of roll, pitch and heading estimations. Such improved accuracy is useful if data from external sensors are not available right at the beginning of the mission. Any movement is allowed during the fine alignment. 90 degrees rotations are even recommended so that the Kalman filter assesses the sensors bias on different axes. The fine alignment is ended automatically by ROVINS when the heading covariance is below 0.1degree.
- At the end of the fine alignment process, ROVINS is ready for navigation with optimal performances.

	0	5	Time in minutes
	When heading standard deviation <0.1		
	Navigation = Static or max speed < 3 knot	Navigation with large heading variations (>90°)	
Heading & Attitude	Invalid output	Reliable output	Full accuracy output
Position	= Position given by the GPS	Reliable output	Full accuracy output
Flag in the System status area	Alignement	Fine Alignement	System ready

MORE...

The previous steps consist only of the basic configuration of your ROVINS system. You will find hereafter a list of other possible configurations. Details on these configurations can be found in the ROVINS User Guide.

ROVINS TO VEHICLE MISALIGNMENT

ROVINS measures heading and attitude with respect to its reference frame defined by the 3 axes X1, X2 and X3 (see Figure 1). ROVINS reference frame may not be parallel to the vehicle reference frame. In such case, heading and attitude outputs can be compensated for angular misalignments of ROVINS relative to the vehicle reference frame so that ROVINS outputs heading and attitude of the vehicle.

This is done by setting misalignment bias for the three reference axis. These biases are the Euler angles which relate ROVINS and vehicle reference frame. Vehicle reference frame is depicted on Figure 2.




Figure 2 - Vehicle Reference Frame

For more details about the misalignment bias, refer to Part 2 of the ROVINS User Guide.

CONFIGURING THE OUTPUT STREAM

ROVINS is able to calculate the heave of several external monitoring point: one primary and three secondary monitoring points can be user-configured. The secondary lever arms are used to compute the heave for the output protocols that provide it (see Part IV- Configuration and Operation of the ROVINS User Guide to define the secondary lever arms), the output position being always given for the Primary lever arm..

External monitoring points are defined by their "Lever Arm" to ROVINS center of measurement P. This lever arm is the triplet of cartesian coordinates (LV1, LV2, LV3) defining the position of external monitoring point M with respect to ROVINS center of measurement P (defined in Figure 1) in the vessel reference frame (XV1, XV2, XV3) - see Figure 3.




Figure 3 - Definition of lever arms

For more details about the external monitoring points, refer to Part 2 of the ROVINS User Guide.

CONFIGURING THE OUTPUT STREAM

ROVINS uses external sensor data to improve its own estimates of position, speed, attitude and, heading. In order to prevent corrupted external data to degrade the estimation of ROVINS, external sensor data pass through a rejection filter before being incorporated into ROVINS main computation Kalman filter.

The following external sensors can be added:

- A DVL
- A LBL
- An USBL (up to three beacons)
- A CTD
- A depth sensor

For more details about the external sensors, refer to part 4 of the ROVINS User GUIDE

ETHERNET INPUT/OUTPUT

Five Ethernet inputs/outputs are available on ROVINS.

For more details about

- **The Ethernet connector, refer to Part 2 of the ROVINS User Guide**
- **The available protocols for this connectors, refer to part 5 of the ROVINS User Guide.**

PULSE INPUT/OUTPUT

Four pulse inputs and two external pulse coming from the central connector are available on ROVINS.

For more details about the pulse connector pins, refer to Part 2 of the ROVINS User Guide.

EXTENDED FUNCTIONS OF THE WEB-BASED USER INTERFACE

Recording data: you can record the data coming from the repeater port or of any of the A to E output. **For more details about the data recording refer to Part 4 of the ROVINS User Guide.**

Observing the input data flow coming from any input stream. For more details refer to Part 4 of ROVINS User Guide.

System Information: to accede to the serial number and firmware version of your ROVINS unit, click on **maintenance** menu of the WEB-based User Interface.

Note: these information are useful when you contact IXSEA technical support.

ROVINS ZERO VELOCITY UPDATE (ZUPT) MODES

These modes have been designed to use ROVINS for specific applications when no external sensor is connected.
For more details about ZUPT mode, refer to part 4 of the ROVINS User Guide.

CUSTOMER SUPPORT

THE WORLDWIDE 24/7 TELEPHONE SUPPORT LINE NUMBERS ARE:

[EMEA +33 (0)1 30 08 98 98
USA +1 888 660 8836 (toll free)
ASIA +65 6747 7027

To contact customer support for any IXSEA products, a general mail box is available with the following address:

support@ixsea.com

IXSEA CONTACT

To obtain information on any IXSEA products, a general mail box is available with the following address:

info@ixsea.com

You can also contact IXSEA headquarters in France, or one of its representatives around the

Contact	Phone	Fax
IXSEA SAS France	+33 (0)1 30 08 98 88	+33 (0)1 30 08 88 01
IXSEA BV The Netherlands	+31 (0)23 750 5110	+31 (0)23 750 5111
IXSEA GmbH Germany	+49 (0)511 123 59575	+49 (0)511 123 59576
IXSEA Ltd - Main office IXSEA Ltd - Aberdeen office United Kingdom	+ 44 1730 260222 + 44 1224 355160	+44 1730 260333
IXSEA LLC United Arab Emirates	+971 4 3117135	+971 4 3328860
IXSEA Inc Usa	+1 (888) 660 8836	+1 (781) 937 8806
IXSEA Pte Ltd Singapore	+65 6747 4912	+65 6747 4913
IXSEA Pte Ltd China	+86 (0)10 6211 4716	+86 (0)10 6211 4718
IXSEA Pty Ltd Australia	+61 (0)7 3390 4660	+61 (0)7 3390 7242

PERSONAL NOTES
